

---

EC230 - 235 - 260

MACCHINA DA CAFFÈ

COFFEE MAKER

KAFFEEMASCHINE

MACHINE À CAFÉ

KOFFIEZETAPPARAAT

CAFETERA

MÁQUINA DE CAFÉ

ΜΗΧΑΝΗ ΓΙΑ ΚΑΦΕ

KAFFEMASKIN

KAFFEMASKIN

KAFFEMASKINE

KAHVINKEITIN

КОФЕМАШИНА

КОФЕ ЖАСАҒЫШ

KÁVÉFŐZŐGÉP

KÁVOVAR

KÁVOVAR

EKSPRES DO KAWY

APARAT ZA KAVU

KAVNI APARAT

КАФЕМАШИНА

APARAT DE PREPARAT CAFEA

KABOBAРKA

UREĐAJ ZA KAFUKAHVE

MAKINESI



ماكينة قهوة





---

**DeLonghi**



**EC230**













**EC235**












**EC260**



# FIRST USE























	<b>EC230</b>	<b>EC235 - EC260</b>
<b>1</b>		
<b>2</b>		

**b1**









**CLEANING AFTER USE**






# MILK SYSTEM

CLEANING AFTER USE  
EC230  
&235












# MILK SYSTEM

CLEANING AFTER USE  
EC260







# HOT WATER









# DESCALING PROGRAM











**45**  
Minutes













**DeLonghi**  
**EcoDecalk**  
100 ml e / 3,40 fl.oz. *mini*



**1L**


























# Troubleshooting



?	!	✓
	<p><b>EC230</b></p>	
	<p><b>EC235</b> <b>EC260</b></p>	
	<p>Limescale</p>	<p><b>DESCALING PROGRAM</b></p>



?	!	✓
		
	 <p data-bbox="684 437 759 496"><b>HINTS &amp; TIPS</b></p> <p data-bbox="423 560 572 592"><b>LIMESCALE</b></p>   <p data-bbox="684 619 759 715"><b>DESCALING PROGRAM</b> PAG. 9</p> 	 
	    	  <p data-bbox="833 1139 964 1299"><b>Service</b></p>
		 <p data-bbox="762 1417 792 1465">8 cm</p> <p data-bbox="997 1417 1039 1465">10,7 cm</p>